

# Application Note AN491

## IoT Subsystem for Cortex-M

Non-confidential

**ARM**<sup>®</sup>

# IoT Subsystem for Cortex-M

Copyright © 2015 ARM. All rights reserved.

## Release Information

The following changes have been made to this SMM.

<b>Change History</b>			
<b>Date</b>	<b>Issue</b>	<b>Confidentiality</b>	<b>Change</b>
25 September 2015	1	Non-confidential	First release

## Proprietary Notice

Words and logos marked with <sup>TM</sup> or <sup>®</sup> are registered trademarks or trademarks of ARM in the EU and other countries except as otherwise stated below in this proprietary notice. Other brands and names mentioned herein may be the trademarks of their respective owners.

Neither the whole nor any part of the information contained in, or the product described in, this document may be adapted or reproduced in any material form except with the prior written permission of the copyright holder.

The product described in this document is subject to continuous developments and improvements. All particulars of the product and its use contained in this document are given by ARM in good faith. However, all warranties implied or expressed, including but not limited to implied warranties of merchantability, or fitness for purpose, are excluded.

This document is intended only to assist the reader in the use of the product. ARM shall not be liable for any loss or damage arising from the use of any information in this document, or any error or omission in such information, or any incorrect use of the product.

Where the term ARM is used it means “ARM or any of its subsidiaries as appropriate”.

## Confidentiality Status

This document is Non-confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by ARM and the party that ARM delivered this document to.

## Product Status

The information in this document is final, that is for a developed product .

## Web Address

<http://www.arm.com>

# Contents

## IoT Subsystem for Cortex-M

<b>1</b>	<b>Conventions and Feedback</b> .....	<b>1-1</b>
<b>2</b>	<b>Preface</b> .....	<b>2-1</b>
2.1	References .....	2-1
2.2	Terms and abbreviations .....	2-1
2.3	Encryption key .....	2-2
<b>3</b>	<b>Overview</b> .....	<b>3-1</b>
3.2	Detailed memory map .....	3-3
3.3	External ZBT Synchronous SRAM (SSRAM1) .....	3-5
3.4	External ZBT Synchronous SRAM (SSRAM2 & SSRAM3) .....	3-5
3.5	External PSRAM .....	3-5
3.6	AHB GPIO .....	3-5
3.7	SPI (Serial Peripheral Interface) .....	3-5
3.8	Color LCD parallel interface .....	3-6
3.9	Ethernet .....	3-6
3.10	VGA .....	3-6
3.11	Audio I <sup>2</sup> S .....	3-7
3.12	Audio Configuration .....	3-8
3.13	FPGA system control and I/O .....	3-9
<b>4</b>	<b>IO mapping</b> .....	<b>4-1</b>
<b>5</b>	<b>Clocks</b> .....	<b>5-1</b>
<b>6</b>	<b>Interrupt assignments</b> .....	<b>6-1</b>
<b>7</b>	<b>Serial Communication Controller (SCC)</b> .....	<b>7-3</b>

# 1 Conventions and Feedback

The following describes the typographical conventions and how to give feedback:

## Typographical conventions

The following typographical conventions are used:

- `monospace` denotes text that you can enter at the keyboard, such as commands, file and program names, and source code.
- monospace denotes a permitted abbreviation for a command or option. You can enter the underlined text instead of the full command or option name.
- monospace italic* denotes arguments to commands and functions where the argument is to be replaced by a specific value.
- monospace bold** denotes language keywords when used outside example code.
- italic* highlights important notes, introduces special terminology, denotes internal cross-references, and citations.
- bold** highlights interface elements, such as menu names. Denotes signal names. Also used for emphasis in descriptive lists, where appropriate.

## Feedback on this product

If you have any comments and suggestions about this product, contact your supplier and give:

- Your name and company.
- The serial number of the product.
- Details of the release you are using.
- Details of the platform you are using, such as the hardware platform, operating system type and version.
- A small standalone sample of code that reproduces the problem.
- A clear explanation of what you expected to happen, and what actually happened.
- The commands you used, including any command-line options.
- Sample output illustrating the problem.
- The version string of the tools, including the version number and build numbers.

## Feedback on documentation

If you have comments on the documentation, e-mail [errata@arm.com](mailto:errata@arm.com). Give:

- The title.
- The number, DAI0491A.
- If viewing online, the topic names to which your comments apply.
- If viewing a PDF version of a document, the page numbers to which your comments apply.
- A concise explanation of your comments.

ARM also welcomes general suggestions for additions and improvements.

ARM periodically provides updates and corrections to its documentation on the ARM Information Center, together with knowledge articles and *Frequently Asked Questions* (FAQs).

#### **Other information**

- ARM Information Center, <http://infocenter.arm.com/help/index.jsp>.
- ARM Technical Support Knowledge Articles, <http://infocenter.arm.com/help/topic/com.arm.doc.faqs/index.html>.
- ARM Support and Maintenance, <http://www.arm.com/support/services/support-maintenance.php>.
- ARM Glossary, <http://infocenter.arm.com/help/topic/com.arm.doc.aeg0014-/index.html>.

The ARM Glossary is a list of terms used in ARM documentation, together with definitions for those terms. The ARM Glossary does not contain terms that are industry standard unless the ARM meaning differs from the generally accepted meaning.

## 2 Preface

This SMM is intended for developers/programmers/users who deploy hardware/software for a purpose.

These topics support the following chapters:

- *References* on page 2-1.
- *Terms and abbreviations* on page 2-1.
- *Encryption key* on page 2-2

### 2.1 References

- *ARMv7-M Architecture Reference Manual ARMv7-A and ARMv7-R edition (ARM DDI 0403D) for Cortex-M products*  
<http://infocenter.arm.com/help/topic/com.arm.doc.ddi0403c/index.html>
- *ARM<sup>®</sup> Versatile<sup>™</sup> Express Cortex<sup>®</sup>-M Prototyping System (V2M-MPS2) Technical Reference Manual*  
[http://arminfo.emea.arm.com/help/topic/com.arm.doc.100112\\_0100\\_03\\_en/index.html](http://arminfo.emea.arm.com/help/topic/com.arm.doc.100112_0100_03_en/index.html)
- *Cortex<sup>®</sup>-M System Design Kit*  
<http://www.arm.com/products/processors/cortex-m/cortex-m-system-design-kit.php>
- *Cortex<sup>®</sup>-M System Design Kit Technical Reference Manual*  
<http://infocenter.arm.com/help/topic/com.arm.doc.ddi0479c/index.html>
- *ARM<sup>®</sup> PrimeCell Synchronous Serial Port (PL022) Technical Reference Manual*  
<http://infocenter.arm.com/help/index.jsp?topic=/com.arm.doc.ddi0194g/I1005344.html>
- *Keil<sup>®</sup> MCBSTM32C Evaluation Board Display Board Schematic*  
<http://www.keil.com/mcbstm32c/mcbstm32c-display-board-schematics.pdf>
- *IoT Subsystem for Cortex-M product page*  
<http://www.arm.com/products/internet-of-things-solutions/iot-subsystem-for-cortex-m.php>

### 2.2 Terms and abbreviations

<b>CMSDK</b>	<i>Cortex-M System Design Kit.</i>
<b>MPS2</b>	<i>Cortex-M Prototyping system, also known as MPS2 (second generation of Microcontroller prototyping system).</i>
<b>FPGA</b>	<i>Field programmable gate array.</i>
<b>SMM</b>	<i>Soft Macrocell Model.</i>
<b>ZBT</b>	<i>Zero bus turnaround</i>
<b>SRAM</b>	<i>Static random access memory</i>
<b>SSRAM</b>	<i>Synchronous SSRAM</i>

## 2.3 Encryption key

ARM supplies the V2M-MPS2 motherboard with a decryption key programmed into the FPGA. This key is needed to enable loading of encrypted, prebuilt images. AN491 is supplied as an encrypted image.

### **Caution**

A battery supplies power to the key storage area of the FPGA. Any keys stored in the FPGA may be lost when battery power is lost. If this happens you must return the board to ARM for reprogramming of the key.

# 3 Overview

The SMM design is based on the IOT Subsystem for Cortex-M and incorporates a Cortex-M3 processor. Cortex-M System Design Kit (CMSDK) components are used for many of the peripherals.

## 3.1.1 Overview




Figure 3-1 System Overview





## 3.2 Detailed memory map

Start Address	End Address	Description	Comment
0x60000000	0x5FFFFFFF	Reserved	
0x41100000	0x4113FFFF	VGA Image	512x128x32bit
0x41010000	0x410FFFFF	Reserved	
0x41000000	0x4100FFFF	VGA Console	
0x40200000	0x40FFFFFF	Ethernet	via ahb_to_extmem16
0x40032000	0x401FFFFF	Reserved	
0x40031000	0x40031FFF	GPIO5	
0x40030000	0x40030FFF	GPIO4	
0x4002F000	0x4002FFFF	SCC register	See SCC section
0x40029000	0x4002EFFF	Reserved	
0x40028000	0x40028FFF	FPGA System Control & I/O	
0x40025000	0x40027FFF	Reserved	
0x40024000	0x40024FFF	Audio I <sup>2</sup> S	
0x40023000	0x40023FFF	SBCon	Audio Configuration
0x40022000	0x40022FFF	SBCon	Touch for LCD module
0x40021000	0x40021FFF	PL022	SPI for LCD module
0x40020000	0x40020FFF	PL022	SPI connector J21
0x4001F000	0x4001FFFF	SysCtrl	CMSDK system controller
0x40012000	0x4001EFFF	Reserved	
0x40011000	0x40011FFF	GPIO1	
0x40010000	0x40010FFF	GPIO0	
0x4000F000	0x40009FFF	Reserved	
0x40008000	0x40008FFF	Watchdog	
0x40006000	0x40007FFF	Reserved	

Start Address	End Address	Description	Comment
0x40005000	0x40005FFF	UART1	
0x40003000	0x40004FFF	Reserved	
0x40002000	0x40002FFF	Dual timer	
0x40001000	0x40001FFF	Timer1	
0x40000000	0x40000FFF	Timer0	
0x22000000	0x3FFFFFFF	Reserved	
0x21000000	0x21FFFFFF	PSRAM	User Memory
0x20800000	0x20FFFFFF	Reserved	
0x20400000	0x207FFFFF	ZBT2&3	User Memory
0x20020000	0x203FFFFF	Reserved	
0x20018000	0x2001FFFF	SRAM3	FPGA Block RAM
0x20010000	0x20017FFF	SRAM2	FPGA Block RAM
0x20008000	0x2000FFFF	SRAM1	FPGA Block RAM
0x20000000	0x20007FFF	SRAM0	FPGA Block RAM
0x00800000	0x1FFFFFFF	Reserved	
0x00400000	0x007FFFFF	ZBT1	User Memory
0x00080000	0x003FFFFF	Reserved	
0x00000000	0x0007FFFF	RAM	Replaces subsystem FLASH RAM

**Table 3-1 Detailed System Memory Map**

### 3.3 External ZBT Synchronous SRAM (SSRAM1)

This is interfaced to two external 32-bit ZBT SSRAM in parallel, forming a 64-bit ZBT SSRAM. This memory is in the processor's code region.

### 3.4 External ZBT Synchronous SRAM (SSRAM2 & SSRAM3)

The Fast ZBT SSRAM is set up as two external ZBT SSRAMs, connected to two independent ZBT interfaces. It is in the processor's SRAM region.

The ZBT SSRAM is interleaved and available to the user as shown in the table below.

Upper 32-bit ZBT SSRAM3	Lower 32-bit ZBT SSRAM2
0x207FFFFC	0x207FFFF8
...	...
0x2040000C	0x20400008
0x20400004	0x20400000

Table 3-2 32 bit ZBT Memory Map

### 3.5 External PSRAM

A 16MB 16-bit PSRAM area is available and the memory map allocates the address-range 0x21000000 -0x21FFFFFF. This enables large test programs to be used.

Note: Running code from SRAM region is slower than from CODE region because the internal bus structure is not optimized for running programs from this region.

### 3.6 AHB GPIO

The SMM uses CMSDK AHB GPIO #0 and #1. GPIO #4 and #5 have been added to increase the number of pins available. See the CMSDK TRM

### 3.7 SPI (Serial Peripheral Interface)

The SMM implements two PL022 SPI modules:

- General purpose SPI module that connects to the general-purpose SPI connector, J21.
- Color LCD module control.

The Color LCD module control interfaces with an Ampire AM-240320LG 2.4" Touch Panel on the Keil MCBSTM32C display board. (Schematic listed in the reference section).

Self-test provided with the MPS2 board includes example code for the color LCD module control interface.

### 3.8 Color LCD parallel interface

The color LCD module has two interfaces:

- SPI for LCD module used for sending image data to the LCD.
- I<sup>2</sup>C for touch used to transfer data input via the touch screen.

These interfaces are connected to a STMicroelectronics STMPE811QTR Port Expander with Advanced Touch Screen Controller on the Keil MCBSTM32C display board. (Schematic listed in the reference section).

Self-test provided with the MPS2 includes example code for both of these interfaces.

### 3.9 Ethernet

The SMM design connects SMSC LAN9220 through AHB to external memory block.

The SMM self-test code includes example code for a simple loopback operation.

### 3.10 VGA

Address	Description
0x41000000 - 0x4100FFFF	Writes to the current location of the cursor.
0x41100000 - 0x4113FFFF	512x128 image area at the top right of the screen. 0x41100000 is the top left of the area and 0x4113FFFF is the bottom right. HADDR[16:2] = YYYYYYYXXXXXXXXX where X and Y are the horizontal and vertical pixel offset respectively.

**Table 3-3 VGA Memory Map**

For the image data, each pixel requires one 32 bit word, therefore, a total of 256KB are needed. The values in the data buffer are packed as 4 bits per-channel in the format 0x00000RGB.

The pixel in the top left hand corner of the display occupies address 0x41100000 with each successive row using an offset of 0x00000400 from the previous row. For example: the left most pixel (LMP) of the 2<sup>nd</sup> row is at 0x41100400 and the LMP of the 3<sup>rd</sup> row is at 0x41100800.

## 3.11 Audio I<sup>2</sup>S

A simple FIFO interface generates and receives I<sup>2</sup>S audio.

Address	Name	Information
0x40024000	CONTROL	Control Register [31:18] : Reserved [17] : Audio CODEC reset control (output pin) [16] : FIFO reset [15] : Reserved [14:12] : RX Buffer IRQ Water Level - Default 2 (IRQ triggers when more less 2 word space available) [11] : Reserved [10: 8] : TX Buffer IRQ Water Level - Default 2 (IRQ triggers when more than 2 word space available) [7: 4] : Reserved [3] : RX Interrupt Enable [2] : RX Enable [1] : TX Interrupt Enable [0] : TX Enable
0x40024004	STATUS	Status register [31:6] : Reserved [5] : RX Buffer Full [4] : RX Buffer Empty [3] : TX Buffer Full [2] : TX Buffer Empty [1] : RX Buffer Alert (Depends on Water level) [0] : TX Buffer Alert (Depends on Water level)
0x40024008	ERROR	Error status register [31:2] : Reserved [1] : RX overrun - write 1 to clear [0] : TX overrun/underrun - write 1 to clear
0x4002400C	DIVIDE	Divide ratio register (for Left/Right clock) [31:10] : Reserved [ 9: 0] LRDIV (Left/Right) Default = 0x80 $12.288\text{MHz} / 48\text{KHz} / 2 (L+R) = 128$
0x40024010	TXBUF	Transmit Buffer FIFO Data Register (WO) [31:16] : Left Channel [15: 0] : Right Channel

Address	Name	Information
0x40024014	RXBUF	Receive Buffer FIFO Data Register (RO) [31:16] Left Channel [15: 0] Right Channel
0x40024018 – 0x400242FC	RESERVED	-
0x40024300	ITCR	Integration Test Control Register [31:1] : Reserved [0] : ITCR
0x40024304	ITIP1	Integration Test Input Register 1 [31:1] : Reserved [0] : SDIN
0x40024308	ITOP1	Integration Test Output Register 1 [31:4] : Reserved [3] : IRQOUT [2] : LRCK [1] : Reserved [0] : SDOUT

**Table 3-4 Audio I<sup>2</sup>S Memory Map**

### 3.12 Audio Configuration

The SMM implements a simple serial interface (SBCon) to the audio codec.

### 3.13 FPGA system control and I/O

The SMM implements an FPGA system control block.

Address	Name	Information
0x40028000	FPGAIO->LED0	LED connections [31:2] : Reserved [1:0] : LED
0x40028004	RESERVED	
0x40028008	FPGAIO->BUTTON	Buttons [31:2] : Reserved [1:0] : Buttons
0x4002800C	RESERVED	
0x40028010	FPGAIO->CLK1HZ	1Hz up counter
0x40028014	FPGAIO->CLK100HZ	100Hz up counter
0x40028018	FPGAIO->COUNTER	Cycle Up Counter Increments when 32-bit prescale counter reach zero.
0x4002801C	FPGAIO->PRESCALE	Bit[31:0] – reload value for prescale counter.
0x40028020	FPGAIO->PSCNTR	32-bit Prescale counter – current value of the pre-scaler counter. The Cycle Up Counter increment when the prescale down counter reach 0. The pre-scaler counter is reloaded with PRESCALE after reaching 0.
0x40028024	RESERVED	
0x4002804C	FPGAIO->MISC	Misc control [31:7] : Reserved [6] : CLCD_BL_CTRL [5] : CLCD_RD [4] : CLCD_RS [3] : CLCD_RESET [2] : RESERVED [1] : SPI_nSS [0] : CLCD_CS

**Table 3-5 System Control and I/O Memory Map**



# 4 IO mapping

EXP Pin	GPIO	EXP Pin	GPIO	EXP Pin	GPIO
EXP_0	GPIO0[0]	EXP_17	GPIO1[3]	EXP_35	GPIO1[12]
EXP_1	GPIO0[4]	EXP_18	GPIO1[4]	EXP_36	GPIO1[13]
EXP_2	GPIO0[2]	EXP_19	GPIO1[5]	EXP_37	GPIO4[10]
EXP_3	GPIO0[3]	EXP_20	GPIO4[4]	EXP_38	GPIO4[0]
EXP_4	GPIO0[1]	EXP_21	GPIO4[5]	EXP_39	GPIO4[1]
EXP_5	GPIO0[15]	EXP_22	GPIO4[6]	EXP_40	GPIO4[2]
EXP_6	GPIO0[5]	EXP_23	GPIO4[7]	EXP_41	GPIO1[6]
EXP_7	GPIO0[6]	EXP_24	GPIO4[8]	EXP_42	GPIO4[11]
EXP_8	GPIO0[7]	EXP_25	GPIO4[9]	EXP_43	GPIO4[12]
EXP_9	GPIO0[8]	EXP_26	GPIO1[0]	EXP_44	GPIO4[3]
EXP_10	GPIO0[9]	EXP_27	GPIO1[9]	EXP_45	GPIO4[13]
EXP_11	GPIO0[13]	EXP_28	GPIO1[8]	EXP_46	GPIO4[14]
EXP_12	GPIO0[10]	EXP_29	GPIO1[15]	EXP_47	GPIO4[15]
EXP_13	GPIO0[11]	EXP_30	GPIO1[1]	EXP_48	GPIO5[0]
EXP_14	GPIO0[12]	EXP_31	GPIO1[7]	EXP_49	GPIO5[1]
EXP_15	GPIO0[14]	EXP_32	GPIO1[11]	EXP_50	GPIO5[2]
EXP_16	GPIO1[2]	EXP_33	GPIO1[14]	EXP_51	GPIO5[3]
		EXP_34	GPIO1[10]		

**Table 4-1 I/O Mapping**

# 5 Clocks

The following table shows the Source Clocks for the system. These clocks are used to derive the clocks in the tables below. These clocks should not be adjusted.

Name	Frequency
OSCCLK[0]	48MHz
OSCCLK[1]	24.576MHz
OSCCLK[2]	25MHz
CFGCLK	0.5MHz
CS_TCK	Determined by debugger
SPICFGCLK	7.5MHz

**Table 5-1 Source Clocks**

The following table shows the Derived Clocks.

Name	Frequency	Division Factor	Multiplication Factor	Derived From
SYSCLK	24MHz	2	1	OSCCLK[0]
AUDMCLK	12.29MHz	2	1	OSCCLK[1]
AUDSCLK	3.07MHz	8	1	OSCCLK[1]
DBGCLK	24MHz	2	1	OSCCLK[0]
SPICLCD	25MHz	2	1	OSCCLK[0]
SPICON	25MHz	2	1	OSCCLK[0]
I2CCLCD	25MHz	2	1	OSCCLK[0]
I2CAUD	25MHz	2	1	OSCCLK[0]
CLK32KI	32KHz	750	1	OSCCLK[0]

**Table 5-2 Derived Clocks**

## 6 Interrupt assignments


Interrupt	Peripheral	Handler name in C header	CMSDK/MPS2 usage
NMI	Watchdog / External	NMI_Handler	Watchdog
IRQ0	Reserved		UART0 RX
IRQ1	Reserved		UART0 TX
IRQ2	UART 1	UART1_Handler	UART1 RX
IRQ3	Reserved		UART1 TX
IRQ4	Reserved		UART2 RX
IRQ5	Reserved		UART2 TX
IRQ6	GPIO 0 combined interrupt	PORT0_COMB_Handler	GPIO 0 combined interrupt
IRQ7	GPIO 1 combined interrupt	PORT1_COMB_Handler	GPIO 1 combined interrupt
IRQ8	Timer 0	TIMER0_Handler	Timer 0
IRQ9	Timer 1	TIMER1_Handler	Timer 1
IRQ10	Dual Timer	DUALTIMER_HANDLER	Dual Timer
IRQ11	Reserved		FPU / SPI #0 and SPI #1
IRQ12	UART overflow	UARTOVF_Handler	UART overflow
IRQ13	Reserved		Ethernet
IRQ14	Reserved		I2S
IRQ15	Touch Screen		DMA
IRQ16	GPIO 0/1 – pin 0	GPIO01P0_Handler	GPIO 0 – pin 0
IRQ17	GPIO 0/1 – pin 1	GPIO01P1_Handler	GPIO 0 – pin 1
IRQ18	GPIO 0/1 – pin 2	GPIO01P2_Handler	GPIO 0 – pin 2
IRQ19	GPIO 0/1 – pin 3	GPIO01P3_Handler	GPIO 0 – pin 3
IRQ20	GPIO 0/1 – pin 4	GPIO01P4_Handler	GPIO 0 – pin 4
IRQ21	GPIO 0/1 – pin 5	GPIO01P5_Handler	GPIO 0 – pin 5
IRQ22	GPIO 0/1 – pin 6	GPIO01P6_Handler	GPIO 0 – pin 6
IRQ23	GPIO 0/1 – pin 7	GPIO01P7_Handler	GPIO 0 – pin 7
IRQ24	GPIO 0/1 – pin 8	GPIO01P8_Handler	GPIO 0 – pin 8
IRQ25	GPIO 0/1 – pin 9	GPIO01P9_Handler	GPIO 0 – pin 9

IRQ26	GPIO 0/1 – pin 10	GPIO01P10_Handler	GPIO 0 – pin 10
IRQ27	GPIO 0/1 – pin 11	GPIO01P11_Handler	GPIO 0 – pin 11
IRQ28	GPIO 0/1 – pin 12	GPIO01P12_Handler	GPIO 0 – pin 12
IRQ29	GPIO 0/1 – pin 13	GPIO01P13_Handler	GPIO 0 – pin 13
IRQ30	GPIO 0/1 – pin 14	GPIO01P14_Handler	GPIO 0 – pin 14
IRQ31	GPIO 0/1 – pin 15	GPIO01P15_Handler	GPIO 0 – pin 15
IRQ32-46	Reserved		
IRQ47	Ethernet		
IRQ48	I2S		
IRQ49-53	Reserved		
IRQ54	GPIO 4 combined interrupt		
IRQ55	GPIO 5 combined interrupt		

**Table 6-1 Interrupts**

# 7 Serial Communication Controller (SCC)

The SMM implements communication between the microcontroller and the FPGA system through an SCC interface.



**Figure 7-1 Diagram of the SCC Interface**

The read-addresses and write-addresses of the SCC interface do not use bits[1:0]. All address words are word-aligned.

Address	Name	Information
0x000	CFG_REG0	Bits[31:0] Reserved
0x004	CFG_REG1	Bits [31:8] Reserved Bits [7:0] MCC LEDs: 0 = OFF 1 = ON
0x008	CFG_REG2	Reserved
0x00C	CFG_REG3	Bits [31:8] Reserved Bits [7:0] MCC switches: 0 = OFF 1 = ON
0x010	CFG_REG4	Bits [31:4] Reserved Bits [3:0] Board Revision
0x014	CFG_REG5	Reserved
0x018	CFG_REG6	Reserved
0x01C	CFG_REG7	Reserved
0x020 – 0x09C	RESERVED	-
0x0A0	SYS_CFGDATA_RTN	32bit DATA [r/w]
0x0A4	SYS_CFGDATA_OUT	32bit DATA [r/w]

Address	Name	Information
0x0A8	SYS_CFGCTRL	Bit[31] : Start (generates interrupt on write to this bit) Bit[30] : R/W access Bits[29:26] : Reserved Bits[25:20] : Function value Bits[19:12] : Reserved Bits[11:0] : Device (value of 0/1/2 for supported clocks)
0x0AC	SYS_CFGSTAT	Bit 0 : Complete Bit 1 : Error
0x0AD – 0x0FC	RESERVED	-
0x100	SCC_DLL	DLL lock register Bits [31:24] DLL LOCK MASK[7:0] - These bits indicate if the DLL locked is masked. Bits [23:16] DLL LOCK MASK[7:0] - These bits indicate if the DLLs are locked or unlocked. Bits [15:1] : Reserved Bit[0] This bit indicates if all enabled DLLs are locked:
0x104 – 0xFF4	RESERVED	-
0xFF8	SCC_AID	SCC AID register is read only Bits[31:24] : FPGA build number Bits[23:20] : V2M-MPS2 target board revision 1 = (B) V2M-MPS2, 2 = (C) V2M-MPS2+ Bits[19:8] Reserved Bits[7:0] number of SCC configuration register
0xFFC	SCC_ID	SCC ID register is read only Bits[31:24] : Implementer ID: 0x41 = ARM Bits[23:20] : Application note IP variant number (note 1) Bits[19:16] : IP Architecture: 0x4 = AHB Bits[11:4] : Primary part number: 491 = AN491 Bits[3:0] : Application note IP revision number (note 1)

**Table 7-1 SCC Register memory map**

<sup>note 1</sup> The variant and revision numbers relate to the rxy number. For example for r1p0 processors the 1 would be the variant number and the 0 would be the revision number.